## **Instructions for Downloading Data from 23X using Palm:**

The Palm screen is "touch" sensitive and items are selected by touching or tapping with the Stylus.

\* The Palm pictured is model 125. You are using model 500 or 515. Any significant differences are noted in green.

1. Insert the Serial Cable into the bottom Port of the Palm.







2. Connect palm cable end to the 'COMPUTER RS-232' port on the 23X (This is the port on the right, note that the ribbon cable should <u>remain connected</u> to the port on the left labeled 'CS I/O').





If at any time the Palm stops responding, Reset the Palm (see Reset Instructions) and repeat the procedure, EXCEPT select "Collect Data Since Last Time" shown in instruction 8

3. Turn on the Palm by pressing the switch at top \*right (not the center as on the 125 model shown). Remove Stylus from the right side of Palm.





4. If the Main Menu is not visible, touch the picture of a house in lower left corner for HOME.



- 5. Select PConnect by touching with stylus.
- 6. Select Station to be downloaded from list. Touch Connect. A "Please Wait" screen will appear while the Palm is attempting to connect.







7. Touch Measurement in upper right corner for drop down menu. Select Collect Data.





8. On Collect Data screen, there are two drop down menus in the center of the screen. On the upper menu, select Store Data on Card if not already selected. And on the lower menu, select Collect All, if not already selected. If repeating the procedure because the Palm failed to respond, on the lower menu, select "Collect Since Last Time."





\*If you receive an error message that says there is no memory card inserted, Click OK, then check to make sure memory card is properly inserted and return to step 4.

9. When "Store Data on Card" and "Collect All" is displayed, select Collect Data. A screen will appear showing progress, both Final Storage Area 1 and 2 will be collected. *This may take several minutes (12) so be patient.* After data collection is complete, a "Data Collection Complete", screen will appear, select OK.





10. Select Disconnect.



11. Remove Cable from 23X. Remove cable from Palm. **DO NOT DISCONNECT THE RIBBON CABLE!** 





12. Replace stylus. **Turn off Palm!** 





## **PALM RESET INSTRUCTIONS:**

1. To reset the Palm, use a paperclip or pen to push in the "Reset" button on the back. \*The "Reset" button is located at the top center on the back of the 500 & 515 model.



